

清洗说明

如何清除出水口水垢:

出水孔在使用一段时间后可能会堆积杂质或结垢, 导致水流变形、流量减小。请打开水源,用力按 压和摩擦橡胶出水孔,可以轻松将杂质或结垢清除。



如何清洁花洒:

- •为保持花洒洁净,请定期清洁。
- •先用清水或中性的液体清洁剂清洗,再用干净的 软布彻底擦干整个表面。
- 切勿使用任何具有酸性和研磨作用的清洁剂。
- •禁止使用钢丝球、钢丝刷等硬质物品清洗,以免 划伤产品外表面。

产品售后保修条款

摩恩产品是在高质量标准及生产工艺下制造的,摩 恩承诺为消费者购买的洁具产品提供有期限免费保 修及终身维修服务。

花洒免费保修期为1年,均自消费者购买日(以摩 恩产品分销商开具的发票或收据上载明日期为准) 起计。

免费保修范围为产品及产品配件由于材质及工艺原 因而造成的故障或损坏。免费保修期内,我们将无 偿为您提供修理服务及更换发生故障的产品或产品 配件。摩恩的售后服务责任仅限于对故障产品的修 理,而不延及您因产品故障而发生的其他损失,法 律另有规定的除外。

您需了解:产品外观碰伤、刻划痕迹,以及滥用及 不正当保养所导致的故障或损坏,均不属于免费保 修范围。即使在免费保修期内,属下列


(1)-(5)情况之一的,需酌情收取修理费用:1.不能出示相符的保修卡和有效购买凭证情况的,2.未按使用说明书告知的使用方法和注意事项造成的故障,

3.自行拆卸、维修、改装所造成的故障和损坏,
4.由于不可抗力等外部原因引起的故障和损坏,
5.由于运输、搬卸、挤压等造成的损坏。

对于保修期外或不在保修范围内的产品,如需维修, 摩恩将酌情收取上门费、人工费及材料费。 本保修条款仅对原始消费者和酒店行业的购买者有 效,并不适用于本产品在工业,商业,贸易和非酒 店行业的使用。

如对本保修条款内容有任何疑问,请拨打400 630 8866 咨询热线,或向当地分销商咨询。

MOEN [®] 摩恩
合格证 Compliance Certification
产品名称 头顶花洒 Product Name <mark>Top Spray Showerhead</mark>
检验员 Inspector
生产日期 Date of Production
富俊江赢科技(上海)有限公司 中国(上海)自由贸易试验区新杨公路 1800弄1号4幢207室 邮编: 201413
Fortune Brands Innovations (Shanghai) Co., Ltd Room 207, Building 4, No. 1, Lane 1800, Xinyang Highway, China (Shanghai) Pilot Free Trade Zone



花洒使用说明

5000054135

NS1336A

通过推钮左右移动,以实现不同的水花功能。

INS13386A - 6/01

MOEN 摩恩


Top Spray Showerhead



M202015 Series

PLEASE CONTACT MOEN FIRST For Installtation Help, Missing or Replacement parts (China) 400-630-8866 www.moen.cn

©2023 Moen Incorporated



Use Instruction

Push the button to move left and right to achieve different spray functions.

Caution

• The product have been passed the functionality test before ex-factory, please do not dismantle by yourself at will.

• Flush the water supply pipes thoroughly to remove debris.


• Recommended working pressure: 0.2~0.5 Mpa (2~5Bar).


The highest working pressure is 0.5Mpa(5Bar). If it exceeds 0.5Mpa (5Bar), a pressure reducer is needed.

• The highest water and environment temperature is 60°C.

Please keep showerhead away from heater, or it may be damaged and cause injury to the user.

Helpful Tools





Function Features

- Shower Spray
- Granular water
- Mixed water

MOEN LIMITED WARRANTY

We offer limited warranty and lifetime maintenance for Moen products, which are all manufactured with high standards of workmanship.

The period of warranty shall start from the date of purchase of the product (according to the invoice or receipt issued by Moen distributors) and shall cover a period of the following: the warranty period for shower is 1 year.

This warranty is your coverage against material and workmanship malfunction or defects in Moen products or components. During the warranty period, we offer free main tenance and changing of malfunctioned products or product components. Moen's after sales service liability is limited to the maintenance of faulty items and does not cover your other losses caused by product malfunction, except for other wise stipulated by law.

Cosmetic damages (scratches, dents, etc.) and malfunction or defects caused by abuse or improper maintenance is not covered by this warranty. Although the warranty period remains valid, in case of the following conditions (1) - (5), the maintenance cost (material cost and labor cost) shall still be charged as the case may be:

1.Corresponding warranty card and valid invoice cannot be presented:


2.Faults were caused by the incompliance with the instructions and precautions provided in the user's manual:

Installation Instructions

- 1. Apply teflon tape to the both end of shower arm. Thread shower arm into supply pipe. Make sure the length is enough to ensure the shower arm is strong enough to hang up the showerhead.
- 2. Assemble the showerhead and make sure there are no leaks

NOTES:

- Ensure the supply line is deep-set enough for hanging up the showerhead.
- The picture is only for your reference. Please take the object as the standard.



3. Damages and faults were caused by self-actuated dismantling, repair and refit;

4. Faults and damages were caused by external factors such as force majeure;

5.Damages were caused by transportation, unloading and extrusion, etc.

This warranty is valid for the original consumers only (including hotel use), and excludes industrial and commercial use of the product (except for hotel use). This card is only responsible for product maintenance rather than any other liabilities

In the event that the product requires maintenance but exceeds the warranty period, or that the product is not covered by this warranty, labor cost and material cost shall be charged as the case may be.

Please call 400-630-8866 or contact local dealer for any auestion.



Cleaning Instructions

How to Clean the Nozzles:

Any debris or mineral build-up may cause the flow stream to become distorted or reduce the flowrate. To remove the debris or mineral build-up, please turn on the water source and press and rub the rubber water outlet firmly.



How to Clean the Shower Body:

- Keep the product clean with clean water or mild liquiddet ergent regularly.
- Rinse it with clean water or mild liquid, and then dry it with soft cloth.
- Do not use acid or abrasive detergents.
- Do not clean the product with hard materials, for example, steel wool, scourer, etc.

INS13366A 5000054126

0021/2025 Seleased 00